



LARGE INDUSTRIAL CHAMBER FURNACE

LCF

www.carbolite.com/products/chamber-furnaces/industrial-furnaces/lcf/

LCF

LARGE INDUSTRIAL CHAMBER FURNACE

The robust construction of LCF industrial chamber furnaces makes them ideal for applications such as the heat treatment of steels and alloy, ceramics sintering and aerospace heat treatment.

The LCF industrial furnace range is often customised in order to precisely meet the user's requirements. This range also provides a foundation upon which a wide range of custom modifications can be added.

Typical examples of which are the more sophisticated control systems and data recording that is required for applications such as AMS 2750F heat treatment under Nadcap. Solutions are available to handle heavier loads or assist in loading and unloading the furnace, or larger chamber sizes than are offered in the standard range.



LCF industrial chamber furnace

LCF

STANDARD FEATURES

- | 1200°C & 1400°C maximum temperatures
- | Programmable EPC3016P1 controller
- | Over-temperature protection
- | Excellent uniformity and control
- | Robust construction using hollow steel section & zinc coated steel sheet
- | Double skin construction ensures safe outer case temperature
- | Manually operated vertically opening door keeps the hot face away from the operator
- | Low thermal mass insulation for high energy efficiency
- | Hard wearing silicon carbide tiled hearth
- | 1200°C range heated by heavy gauge wire elements in roof and below the hearth
- | 1400°C range heated by high quality silicon carbide elements in roof and below the hearth
- | Safety door interlock isolates power from the elements whenever the door is opened
- | Ethernet communications

LCF

OPTIONS

Specify these at time of order.

- | A range of sophisticated digital controllers, multisegment programmers and data loggers with digital communication options is available — more information about controllers: www.carbolite.com/products/control-options/
- | Pneumatically or electrically operated doors
- | Remote control module
- | A range of retorts can be supplied for using modified with atmospheres up to 1000°C
- | Bespoke specifications are available for AMS2750F (Nadcap) compliant applications

LCF

TECHNICAL DATA

1200°C RANGE

Model	LCF 12/202	LCF 12/405	LCF 12/560	LCF 12/675	LCF 12/720
Max temp (°C)	1200	1200	1200	1200	1200
Max continuous operating temp (°C)	1150	1150	1150	1150	1150
Internal H × W × D (mm)	300 × 600 × 1120	450 × 750x × 1200	500 × 750 × 1500	500 × 750 × 1800	600 × 1000 × 1200
External H × W × D (mm)	2310 × 1180 × 1590	2620 × 1440 × 1750	2700 × 1500 × 2300	2700 × 1500 × 2600	2950 × 1575 × 1810
Volume (litres)	202	405	560	675	720
Max power (W)	24000	35000	45000	60000	60000
Thermocouple type	R	R	R	R	R

1400°C RANGE

Model	LCF 14/125	LCF 14/350	LCF 14/480	LCF 14/725
Max temp (°C)	1400	1400	1400	1400
Max continuous operating temp (°C)	1400	1400	1400	1400
Internal H × W × D (mm)	250 × 500 × 1000	400 × 760 × 1130	500 × 800x × 1200	500 × 720 × x 1790
External H × W × D (mm)	2310 × 1340 × 1650	2545 × 1549 × 1800	2560 × 1650 × 1900	2620 × 1480 × 2470
Volume (litres)	125	350	480	725
Max power (W)	30000	48000	60000	60000
Thermocouple type	R	R	R	R

LCF

CONTACT US →

www.carbolite.com/contact-services/contact-form/?prefilltext=contact_form.request&product=C-2-IBF-B

REQUEST A QUOTE →

www.carbolite.com/contact-services/contact-form/?prefilltext=contact_form.quote_request&product=C-2-IBF-B



CARBOLITE[®]
a **VERDER** company

www.carbolite.com/products/chamber-furnaces/industrial-furnaces/lcf/

© Carbolite Gero – www.carbolite.com / Content may be subject to modifications or corrections